



# Parata PASS 500<sup>®</sup> Pouch Packager

## Key Features

**Intuitive Software:** Parata PASS Ware<sup>®</sup> software is flexible and easy to use. It offers a wide range of reporting, a drag-and-drop editor to customize pouch design, and the ability to include header, footer, and reminder pouches.

**Scalability:** Smart canisters extend capacity beyond the standard configuration. Store additional canisters outside the unit and swap them in as needed.

---

## Capacity

Up to 500 canisters (or unique NDCs) at one time

## Pharmacy Software Integrations

Parata integrates with nearly 50 host systems

## Included with Your Purchase of a Parata PASS Packager

- NDC-specific canisters (500) and canister labels
- Special tablet trays (3)
- Laser printer (1) and Dymo printer (1)
- Precisa LS 2200C Scale
- Cleaning kit
- PASS Pack boxes, assorted
- Paper (5 rolls) and ribbon (5 rolls)
- Parata PASS Ware license and workstation, which includes: standard PC tower, 22-inch widescreen monitor, keyboard, mouse, printer, and barcode scanner

## Optional Complements

- Parata PASS Safe Loader<sup>®</sup> Lighted Tray
- Parata Perl<sup>™</sup> Pouch Inspector
- Parata Pivot<sup>™</sup> Workflow Software
- iRolly, Winder DE

---

## Network Requirements

Ethernet RJ-45

## Power Requirements

PASS Packager: One dedicated 120V / 60Hz outlet within 6 feet of the packager.  
PASS Ware Workstation: Connection to uninterruptable power supply (UPS) and access to 120 V / 15A / 60Hz outlets.

# Parata PASS 500<sup>®</sup> Pouch Packager

Position high-volume medication canisters — available in three sizes — for easy refilling



Ensure a match between the drug and smart canister with barcode scanning.

Manage one-off meds, OTCs, half tabs, and more with STS trays.




Create custom pouch designs by patient or facility.



Expect flexibility and control with easy-to-use software.

Retrieve PASS strips easily after packaging.



Dimensions	Width (in)	Height (in)	Depth (in)
Packager	43	91	47½
Total Space	115	96*	115½

You'll also need counter space for the PASS Ware workstation.

\*During assembly, 105" height space is needed.

Weight	Unloaded (lb)	Loaded (lb)
Packager	2,558	Up to 3,050