



Parata PASS™ 208 Pouch Packager

Key Features

Scalability: Smart canisters extend capacity beyond the standard configuration. Store additional canisters outside the unit and swap them in as needed.

Efficiency: Auto canisters allow for easy swapping between drugs for changing fomulary, while also dispensing partial pills.

Intuitive Software: Parata PASS Ware® software is flexible and easy to use. It offers a wide range of reporting, a drag-and-drop editor to customize pouch design, and the ability to include header, footer, and reminder pouches.

Capacity

Up to 208 canisters (or unique NDCs) at one time

Pharmacy Software Integrations

Parata integrates with nearly 100 host systems

Included with your Purchase of a Parata PASS Packager

- NDC canisters (208) and labels
- Auto canisters in unit (2)
- Special tablet trays (3)
- Laser printer (1) and Dymo printer (1)
- Precisa LS 2200C Scale
- Cleaning kit
- Parata PASS Ware license and workstation

Optional Complements

- Parata Perl® Pouch Inspector
- Parata Pivot® Workflow Software
- Parata PASS Safe Loader® Lighted Tray
- Canister build kit
- iRolly, Winder DE
- Auto canisters

Power/Space Requirements

PASS Packager: One dedicated 120V / 60Hz outlet within 6 feet of the packager.
 PASS Ware Workstation: Connection to uninterruptable power supply (UPS) and access to 120 V / 15A / 60Hz outlets located within 6 feet of the unit with a direct connection.

Network Requirements

Ethernet RJ-45 (Cat VI)

Parata PASS™ 208 Pouch Packager

Maximize your small space with hinged storage for canisters.



Build and re-build adjustable smart canisters on demand to save time with quick-changing medications with PASS Canister Build Kit.



Manage one-off meds, OTCs, half tabs, and more with STS trays.




Create custom pouch designs by patient or facility.

Roll it into your pharmacy through a standard door frame.



Expect flexibility and control with easy-to-use software.

Retrieve PASS strips easily after packaging.



Dimensions	Width (in)	Height (in)	Depth (in)
Packager	39	82	25
Total Space	67	96	69

You'll also need counter space for the PASS Ware workstation.

Weight	Unloaded (lb)	Loaded (lb)
Packager	662	775+