

Parata PASS Safe Loader™ Special Tablet System



Manage one-off medications, over-the-counter drugs and slow movers with safety and ease.

Parata PASS Safe Loader takes the uncertainty out of managing one-off medications, over-the-counter drugs, 1/2 tabs, supplements and other slow movers.

Prepare medication trays quickly and accurately.

Our light-to-fill tray, Parata PASS Safe Loader, automates the preparation of special tablet system (STS) trays for increased efficiency and accuracy. Just follow the lights.

Simply set a RFID-capable STS tray in the lighted load station and let the Safe Loader software guide your tray preparation. Safe Loader uses LED lights in each cell to illuminate where each pill needs to be dropped. The software requires users to scan the stock bottle UPC for a barcode match before dropping the pill. Sensors in the cell detect the pill drop, and the LED light turns green to indicate a successful drop. If a pill is dropped into a wrong cell or there is an unintended drop, that cell will illuminate red.

Our RFID-capable STS trays use radio frequency to share information between the Safe Loader software and the PASS packager, correctly identifying each patient's medications within each batch. PASS will package medications only when the correct tray is placed in the unit.

Streamline your workflow.

Adding Safe Loader to your pharmacy establishes a distinct workstation for all STS drug preparation and creates a safe, repeatable process for consistency and accuracy across shifts and users — new and experienced.

Safe Loader facilitates organization, eliminates printed paper reports, and reduces the need for multiple checks and pharmacist verification of STS trays, helping your pharmacy save time and resources.

Ensure security and accountability.

With manual methods, it can be difficult to determine who prepared an STS tray in the event of a medication error. In addition to ensuring accuracy in dispensing, Safe Loader promotes security and accountability by requiring authorized users to log in to the software with a unique RFID key fob before preparing medications.

Expect easy integration.

Parata PASS Safe Loader is part of a complete adherence packaging solution that also includes Parata PASS packagers and Parata Check PASS™.

Parata PASS Safe Loader includes:

- Safe Loader lighted STS load station
- 5 RFID-enabled STS trays
- PC workstation running Parata PASS Safe Loader software
- Barcode scanner
- RFID readers for user login

Parata PASS Safe Loader™ Special Tablet System

SPACE REQUIREMENTS

You will need enough counter space for Parata PASS Safe Loader (25¾" x 16½"); a PC workstation with a monitor, keyboard, mouse and scanner; access to the pharmacy network or the PASS router; and space nearby to place stock bottles while using Safe Loader.



ELECTRICAL REQUIREMENTS

- Three 120V, 15A, 60Hz outlets



CTPASSL-SPEC-0714-1k

©2014 Parata Systems, LLC. All rights reserved.

Parata, Parata Safe Loader and Parata Check PASS are trademarks or registered trademarks of Parata Systems, LLC.